

Tools required for installation:

- Spirit level - tape measure - screw driver/cordless drill - fixing nail gun(not framing gun)
- Hammer - liquid nails

1. Mark the walls with straight lines across the surface you wish to cover the same distance apart as the panels you are going to hang. Use these lines as a guide to keep the panels straight.



2. Apply liquid nails with a silicone gun or timber glue with a notched trowel to the wall area.



3. Press the panel firmly against the wall making sure that it is square and the gaps between each panel is closed tight



PS:

To gain a more secure fix to the wall, use a fixing gun (NOT a framing gun) to shoot a fixing nail through gaps in the timber pieces.



For a brick wall installation you will need to build a small batter stud wall against the bricks. Then line the stud wall with plywood.

